


Figures and symbols on the thermostat



Temperature Settings

0 = isolation of the radiator

☼ = Frost protection symbol (in this position the valve opens automatically when room temperature drops below 44 °F.)

1 = about 54 °F

2 = about 61 °F

3 = about 68 °F

4 = about 75 °F

5 = about 82 °F

} The minor graduations between the figures 2 – 4 represent a change of room temperature of about 2 °F.

Thermostat setting applications

0 - isolation of the radiator

☼ - frost protection

1 - basement

2 - bedroom, hallway

3 - basic setting "3": living room, kitchen, children's room

4 - bathroom

5 - swimming pool room (the setting between "4" and "5" should not be selected under normal conditions because of energy saving reasons)